

## 8.0 HHMS-9XW08 Transmitter Specifications

Table 2. HHMS-9XW08 Transmitter Specifications

Item	Description	
<b>Power</b>	<b>V<sub>in</sub></b>	+6V to +8.4V
	<b>Source</b>	Rechargeable Lithium Ion Battery Pack
	<b>Low Battery Warning</b>	6.6V – batteries should be immediately replaced
	<b>Low Battery Shutdown</b>	6.1V – batteries must be replaced to operate
<b>Environment</b>	<b>Operating Temp</b>	-4°F to 140°F (-20°C to 60°C)
	<b>Storage Temp</b>	-22°F to 158°F (-20°C to 70°C)
	<b>Humidity</b>	0–95% non-condensing
<b>Radio</b>	<b>Frequency</b>	904–926 MHz @ 100mW
	<b>License</b>	No license required
	<b>Modulation</b>	DSSS
	<b>Antenna</b>	Internal
<b>Enclosure</b>	<b>Dimensions</b>	76.2mm x 220.98mm x 42.67mm 3.0" x 8.7" x 1.68"
	<b>Weight</b>	1.43 lb. / 650g
	<b>Durability</b>	High Impact Polymer case Polycarbonate faceplate
<b>Indicators</b>	<b>Radio Frequency</b>	Indicates wireless communications (transmit/receive)
	<b>Battery</b>	Indicates battery status
	<b>A</b>	Indicates Crane A selected when lit (or Receiver A for tandem systems)
	<b>B</b>	Indicates Crane B selected when lit (or Receiver B for tandem systems)
<b>Buttons</b>	<b>Eight</b>	Two-Step actuators